

## **Fitting Instructions for Mono Pitch Canopy**

- 1 Mark a vertical line, using a level, half the internal width of your canopy from the centre of your door ( eg1040 canopy 520mm from centre)
- 2 Hold a gallows bracket against the wall, at the required height, (normally just above the top of the door frame) so that the inner edge is on the line drawn.
- 3 Mark the bottom gallows bracket hole position
- 4 Remove bracket and drill hole 10mm diameter 80mm deep
- 5 Hold bracket back in place and knock plug and screw through bracket in to drilled hole, partially tighten
- 6 Using spirit level ensure bracket is vertical and mark top hole
- 7 Move bracket to one side and drill top hole 10mm dia x 80mm deep
- 8 Reposition bracket and knock plug and screw into place and tighten both screws
- 9 Mark a vertical line on the wall on the other side of the door the internal width of your canopy from the inner edge of the fixed bracket
- 10 Using a spirit level position the second bracket ensuring it is vertically straight and level with the first bracket
- 11 Mark, drill and position second bracket as per instructions 3, 4 & 5
- 12 Carefully using 2 people lift the canopy on to the 2 fixed brackets to check every thing is lined up
- 13 Insert 4 screws through the gallows brackets into the canopy
- 14 Apply caps to all screws ( provided in fixing kit)

